



AUTOMATIC PUMP TRAP APST

DESCRIPTION

The ADCAMat APST automatic pump trap is specially recommended where stall condition may occur due to poor steam trap condensate discharge capacity, caused by temporary insufficient pressure drop.

The equipment combines the features of a float steam trap and a pressure operated pump, in one single unit.

Whenever the steam trap function is incapable of draining condensate, the pump function is activated (using external steam pressure). The pump replaces the necessary positive pressure to lift the condensate to the return system, before water logging occurs, avoiding water hammer and consequent noise, equipment damage, corrosion, unstable temperature control, etc.





No electric requirements. No NPSH issues. Operation under vacuum conditions. No motive or flash steam is lost.

Low filling head for minimal installation space requirements.

OPTIONS:	Level gauge.							
USE:	Drain and lift condensate from heat exchangers (among others). APSTS – carbon steel. APSTS-HC – carbon steel, high capacity. APSTSS – stainless steel. APSTSS-HC – stainless steel, high capacity.							
AVAILABLE MODELS:								
SIZES:	2" x 2" and 3" x 2". DN 50 x 50 and DN 80 x 50.							
CONNECTIONS:	Flanged EN 1092-1 PN 16. Flanged ASME B16.5 Class 150. Female threaded ISO 7 Rp (threaded flanges). Others on request.							
INSTALLATION:	Horizontal installation in a closed loop system. See IMI – Installation and maintenance instructions.							





MOTIVE GAS: Steam.

CE MARKING – GROUP 2 (PED – European Directive)										
PN 16 Category										
All sizes 2 (CE marked)										





OPERATING LIMITING CONDITIONS							
Minimum density	0,80 kg/L						
Maximum motive pressure	10 bar						
Minimum motive pressure	1 bar						
Pump discharge per cycle (approx.)	22 L						

Remark: It is recommended that the motive pressure does not exceed 1 to 4 bar above the expected back pressure applied to the pump.

	FLOW RATE CA		
MOTIVE PRESSURE (bar)	TOTAL LIFT (bar)	2" x 2" DN 50 x 50	3" x 2" DN 80 x 50
1		2290	2640
2		3130	3610
3		3530	4070
4	0,35	3810	4390
6		3910	4500
8		3960	4570
10		3970	4580
2		2520	2910
3		2960	3420
4		3130	3610
6	1	3220	3710
8		3250	3750
10		3290	3800
3		2440	2810
4		2590	2990
5	2	2800	3220
6	2	2830	3270
8		2850	3290
10		2870	3300
4		2330	2680
5		2510	2900
6	3	2530	2920
8		2560	2960
10		2620	3030
5		2250	2600
6	4	2430	2810
8	7	2470	2860
10		2510	3010
6		2050	2370
8	5	2150	2490
10		2190	2540
7		1850	2140
8	6	1910	2210
10		2120	2450

BODY LIMITING CONDITIONS *

APS	STS	APSTSS					
PN 16 / C	LASS 150	PN 16 / CLASS 150					
ALLOWABLE PRESSURE	RELATED TEMPERATURE	ALLOWABLE PRESSURE	RELATED TEMPERATURE				
16 bar	50 °C	16 bar	50 °C				
14 bar	100 °C	15 bar	100 °C				
13 bar	195 °C	12,7 bar	200 °C				
12 bar	250 °C	12 bar 250 °C					

Min. operating temp.: -10 °C; Design code: AD-Merkblatt. * Rating according to EN 1092-1:2018.

	RESERVOIR SIZING TABLE FOR EQUALIZED, CLOSED SYSTEM INSTALLATION														
FLOW		RESERVOIR SIZE (DN)													
RATE	40	50	80	100	150	150 200									
(kg/h)		RESERVOIR LENGTH (mm)													
≤ 300	1200	700	-	_	_	-	_								
400	1500	1000	-	—	-	-	-								
500	2000	1200	500	-	-	-	-								
600	-	1500	600	-	-	-	-								
800	-	2000	800	500	-	-	-								
1000	-	- – 1000		700	-	-	-								
1500	-	_	1500	1000	-	-	-								
2000	_	_	2000	1300	600	-	-								
3000	-	-	-	2000	900	500	-								
4000	-	-	-	-	1200	700	-								
5000	-	-	-	-	1400	800	500								
6000	-	-	-	-	1700	1000	600								
7000	_	_	-	_	2000	1200	700								
8000	-	-	-	-	-	1300	800								
9000	_	-	-	_	_	1500	900								
10000	-	-	-	-	-	1700	1000								

Remark: Reservoir length can be reduced by 50% when the motive pressure divided by the back pressure is ≥ 2 .

CAPACITY MULTIPLYING FACTORS FOR OTHER FILLING HEADS										
FILLING HEAD "H" (mm)										
PUMP SIZE	150	300	600	900						
All sizes 0,7 1 1,2 1,35										
Demonster Filler	haad "II" ia aha									


Remark: Filling head "H" is shown in Fig. 1.


	FLOW RATE CAPACITY (kg/h) OPERATING IN STEAM TRAP MODE													
MODEL	0175	DIFFERENTIAL PRESSURE (bar)												
MODEL	SIZE	0,1	0,3	0,5	0,7	1	1,5	2	4,5	7	10			
APST	2" x 2" – DN 50 x 50	1800	3000	3900	4450	5000	6100	7100	10000	13750	16000			
APST-HC	2" x 2" – DN 50 x 50	2400	5900	7550	9050	11000	14000	15500	22500	26500	30000			
APST	3" x 2" – DN 80 x 50	1800	3000	3900	4450	5000	6100	7100	10000	13750	16000			
APST-HC	3" x 2" – DN 80 x 50	2400	5900	7550	9050	11000	14000	15500	22500	26500	30000			

VALSTEAM ADCA









	DIMENSIONS (mm) – PN 16																	
SIZE	A *	в*	с	C1	D	Е	F	G	н	I	J	L	м	N	O **	P **	WGT. (kg)	VOL. (L)
DN 50 x 50	910	726	212	97	542	356	200	210	512	490	17	18	250	30	1/2"	1"	84	45
DN 80 x 50	924	728	212	97	542	356	200	210	512	490	17	18	250	30	1/2"	1"	91	45


	DIMENSIONS (mm) – CLASS 150																	
SIZE	A *	В*	с	C1	D	Е	F	G	н	I	J	L	м	N	0 **	P **	WGT. (kg)	VOL. (L)
2" x 2"	958	743	212	97	542	356	200	210	512	490	16	18	250	30	1/2"	1"	86	45
3" x 2"	980	748	212	97	542	356	200	210	512	490	16	18	250	30	1/2"	1"	90	45


* Dimensions are different if threaded flanges are requested; ** As standard, in versions manufactured with EN 1092-1 PN 16 flanges, these connections are female threaded ISO 7 Rp. In versions with ASME B16.5 flanges, these connections are female threaded NPT.

VALSTEAM ДДСД









		MATERIALS					
POS. Nº	DESIGNATION	APSTS	APSTSS				
1	Body	P265GH / 1.0425 ; P235GH / 1.0345 ; S235JR / 1.0038	AISI 316 / 1.4401; AISI 316L / 1.4404				
2	Cover	GJS-400-15 / 0.7040	A351 CF8M / 1.4408				
3	* Cover gasket	Non asbestos	Non asbestos				
3.1	* Outlet cover gasket	Non asbestos	Non asbestos				
4	* Inlet valve / Seat assembly	Stainless steel	Stainless steel				
5	* Exhaust valve / Seat assembly	Stainless steel	Stainless steel				
6	Pump mechanism	Stainless steel	Stainless steel				
7	*Float	Stainless steel	Stainless steel				
8	* Spring assembly (2 pieces)	Inconel	Inconel				
9.1	* RD40 outlet check valve	A351 CF8M / 1.4408	A351 CF8M / 1.4408				
9.2	* RD40 Inlet check valve	A351 CF8M / 1.4408	A351 CF8M / 1.4408				
10	Bolts	Steel 8.8	Stainless steel A2-70				
11	** PN 16 EN 1092-1 flanges	P250GH / 1.0460	AISI 316 / 1.4401				
12	* Steam trap unit	Stainless steel	Stainless steel				
13	* Steam trap float	Stainless steel	Stainless steel				
14	Level gauge cocks	Bronze / Stainless steel	Stainless steel				
15	Tube glass	Borosilicate	Borosilicate				

* Available spare parts. ** Welding neck EN 1092-1:2018 flanges.

VALSTEAM ADCA





SIZING AND INSTALLATION

SIZING

To accurately size a pump trap, the following information must be provided:

1. Heat exchanger (or process equipment) maximum steam or condensate load, in kg/h.

2. Heat exchanger (or process equipment) operating pressure at full load in bar g or, alternatively, the heat exchanger maximum operating pressure in bar g and the over design percentage.

3. Motive steam pressure available to operate the pump trap, in bar g.

4. The total lift or back pressure the pump will have to overcome. This includes the change in the fluid level elevation after the pump (0,0981 bar/m of lift), plus pressure in the returning pipe, plus the pressure drop caused by pipe friction, plus any other system component pressure drop the pump will have to overcome, in bar g.

5. Maximum controlled temperature of the medium to be heated (secondary fluid outlet temperature), in °C.

6. Minimum temperature of the medium to be heated (secondary fluid minimum inlet temperature), in °C.

7. Installation head available "H" (see Fig. 1) in mm or any other dimension that allows its determination.

For information on how to predict stall refer to IS 9.085 Technical Information Sheet - Understanding stall condition - or consult the manufacturer.

RESERVOIR

A reservoir is recommended to temporarily hold the liquid and prevent any flooding of the equipment, while the pump is performing a pumping cycle. A length of pipe of large diameter can be used (see reservoir sizing table).

NOTE: All ADCAMat automatic pump traps feature two mechanisms, combining the characteristics of a float steam trap and a pressure operated pump.

When certain that the system backpressure is always superior to the equipment upstream pressure then an ADCAMat pressure operated pump (without steam trap) is the ideal solution as long as it is installed in a closed loop.

In extreme cases, where the system condensate load is above the discharge capacity of all ADCAMat automatic pump trap models, it is recommended to install an ADCAMat pressure operated pump in combination with a high capacity FLT series steam trap. In these scenarios, please consult manufacturer.




Fig.1

VALSTEAM ДДСД





OPERATION

1. In the first instance, the steam intake valve is closed, while the vent valve is open. As condensate flows into the body through the inlet check valve, the APST can operate in a closed loop application, in one of two ways (as a steam trap or pressure operated pump).

2. If the inlet pressure is greater than the back pressure, the APST works as a steam trap, continuously discharging condensate by differential pressure. At this point the steam intake valve remains closed and the vent valve open.

3. As soon as, e.g., the equipment's control valve starts to modulate, the steam pressure will decrease. The lower differential pressure decreases the APST's ability to discharge as a steam trap, causing the condensate level to rise inside the body. Vacuum may even occur at this stage.

4. If this situation would persist, the condensate would eventually flood the equipment, causing problems. However, by using an APST, as the float reaches its highest position, the snap action mechanism actuates, closing the vent valve and opening the steam intake valve. Steam will then replace the necessary positive pressure to pump out the condensate. At this point the APST works as a pressure operated pump.

5. The float starts to fall as the condensate level inside the body drops and is discharged to the return system. When the float reaches its lowest position, the snap action mechanism resets.



6. As the motive steam valve closes and the vent valve opens, equalizing the body pressure with the upstream pressure, the condensate is allowed to flow once again into the APST. The cycle then repeats itself and, with enough differential pressure, the APST resumes as a steam trap or, otherwise, as a pump.

